

Walk-and-Talk™ Interactive Whiteboard Presentation Series

Collaborate
Inspire
Captivate



Intuitive Remote Control



PolyKey™ Technology



Power and Data Track *

* Walk-and-Talk board shown on Power and Data Track System over a 9000 Series Whiteboard

Work the way you want with PolyVision's Walk-and-Talk™ Presentation Series Interactive Whiteboard.

The Freedom to Move and Inspire

The Walk-and-Talk Presentation Series allows you to walk among your audience while controlling your presentation and whiteboard activities through an incredibly intuitive remote control. The remote control puts the power and flexibility of the Walk-and-Talk board in your hands, allowing you to project, write with projected ink, erase, save, print, and access the Web.

Launch your ideas, not your board's software

The Walk-and-Talk board may be used with any PC or laptop, any time, any place, with PolyKey™ technology for instant plug-and-play.


Maximize Your Impact

For even more flexibility, install the system's optional track with embedded power and data to optimize your wall and writing surface space.

Walk-and-Talk Presentation Series:
Don't just present - inspire.

POLYVISION
A Steelcase Company

Features and Technical Specifications



Interactive Whiteboard	Model 1400	Model 1600	Model 1800
Dimension A (HXW)	44.6" x 47.8" (1133mm x 1214mm)	52.6" x 67.8" (1336mm x 1722mm)	52.6" x 97.8" (1336mm x 2484mm)
Dimension B (HXW)	35.0" x 45.0" (889mm x 1143mm)	43.0" x 65.0" (1092mm x 1651mm)	43.0" x 95.0" (1092mm x 2413mm)
Dimension C (Diagonal)	57.0" (1448mm)	78.0" (1981mm)	104.0" (2642mm)
Dimension D (Depth)	4.3" (110mm)	4.3" (110mm)	4.3" (110mm)
Resolution	8000 x 8000	8000 x 8000	8000 x 8000
Weight	52 lbs (23.6kg)	78 lbs (35.4kg)	104 lbs (47.0kg)

Surface material

Touch-sensitive, Teflon® coated, dry erase, low glare, projection-optimized surface

Power Requirements

120V/240V, 50-60hz, 5W, wall-mounted power supply

Certification

FCC class A, CE

Driver/Software Features

- Run PolyKey driver for walk-up-and-use operation or Webster™ software for advanced users
- On screen keyboard and image mark-up
- Print or save images in PDF, BMP, TIFF, PNG, or JPG image format (other options available with Webster software)

Warranty

- Two year limited warranty, free upgrade to five years upon product registration

Options

- Sliding Power and Data Track System
- Room-blasting infrared wireless computer connection

Power and Data Track System

The Walk-and-Talk Power and Data Track System combines the ultimate space flexibility with aesthetics; hiding unsightly power cords and allowing users to slide their Walk-and-Talk board along the track, multiplying writing space and enhancing presentation capabilities. For optimal flexibility, specify track system that is at least double the length of your Walk-and-Talk board.

Computer Requirements

Microsoft Windows®:
Pentium® processor, 32 MB RAM, Windows 98, 2000, ME, XP, and Tablet XP
One available USB port

Apple Macintosh®:

PowerBook®, G3, G4, iBook®, iMac™, or eMac™,
Mac OS 8.6, 9, or X; 32 MB RAM
One available USB port

Accessories (Included)

- Remote control with built-in touch pad and trigger-click technology (two AA batteries included)
- Active infrared eraser with two spare eraser pads (two AAA batteries included)
- Power adapter with 15' (4.6m) cord
- 15' (4.6m) USB cable
- USB PolyKey™ driver
- Stylus
- Getting started guide
- Reversible remote control holder, mounts to either side of board
- Wall mounting brackets
- Two remote control lanyards

Track System	(HxWxD)
PD 0080* 8' Base Unit	4.2" x 96.0" x 1.7" (106.7mm x 2438.0mm x 43.2mm)
PD 0004 4' Extension	4.2" x 48.0" x 1.7" (106.7mm x 1219.0mm x 43.2mm)
PD 0008 8' Extension	4.2" x 96.0" x 1.7" (106.7mm x 2438.0mm x 43.2mm)
PD 0001* Endcaps pair	4.2" x 1.5" x 1.7" (106.7mm x 38.1mm x 43.2mm)

*Base unit and endcaps are required for system operation

Authorized PolyVision Dealer

PolyVision Corporation
1.800.620.POLY
info@polyvision.com
www.polyvision.com

POLYVISION
A Steelcase Company