

TECHNICAL NOTES BULLETIN

NOTEM



N° **05/002**

Date : 10/14/2005

Page : 2/2


Subject

IMPORTANT FEATURES OF THE NEW ALTUS & OREA MOTORS

NEW Altus & Orea Functioning (CMO not affected yet) with a Soliris RTS Sensor

1. All ALTUS & OREA RTS motors produced in 2005, now come set in MANUAL MODE (wind only) as a default and AUTO MODE (wind & sun) needs to be activated via the TELIS SOLIRIS RTS Transmitter.
2. A manual button press overrides AUTO MODE for a period of 15 min. and then returns to AUTO MODE. If an IP position was set it will go to that position once returning to AUTO MODE.
3. AUTO MODE with an IP position is normally used to shade the interior of the house. When sitting under the awning, it is recommended to put the motor into MANUAL MODE. Otherwise the awning will always try to maintain the IP position as illustrated below.

After a MANUAL down order




MANUAL
Wind mode

AUTO
Wind & Sun mode



TELIS SOLIRIS PATIO

After a MANUAL up order



somfy.